

COOKTOP CLEANER & PROTECTOR



Magic Cooktop Cleaner & Protector features a non-scratch formula that removes burnt-on food, grease, grime and watermarks from glass, ceramic, induction and enamel cooktops. It cleans and polishes surfaces to restore shine while leaving a light protective film that helps prevent future marks and makes ongoing cleaning easier.

With a convenient built-in applicator, it is easy to use and delivers effective cleaning without harsh scrubbing. Its versatile formula is also ideal for removing soap scum and watermarks from shower glass and ceramic tiles, making it a handy cleaning solution for both kitchens and bathrooms.

RETAIL PACK INFORMATION

200g Bottle - SKU# 11-200

Description	Dimensions	Unit Qty
200g	W78 x D42 x H180mm	1
Inner	W63 x D260 x H182mm	6
Carton	W270 x D435 x H200mm	36
EAN	9312066000520	

FEATURES:

- ① Removes Baked on Grease & Grime
- ② Cleans & Polishes Glass, Ceramic & Enamel Cooktops
- ③ Leaves a Protective Film to Help Prevent Future Marks
- ④ Non-Scratch Formula

BENEFITS & POINT OF DIFFERENCE

- ✓ Built-in Applying Sponge
- ✓ Makes Future Cleaning Easier
- ✓ Readily Biodegradable



IDEAL FOR:

- Glass Cooktops
- Ceramic Glass
- Enamel Cooktops
- Induction Cooktops
- Shower Screens
- Ceramic Tiles


HANDY HINT:

For best results, regularly clean your cooktop to prevent grease and food residue from becoming baked on and harder to remove.

GLASS INDUCTION COOKTOP



SHOWER GLASS



MANY USES

POWERFUL CLEANING. SPARKLING RESULTS.



FOR MORE INFORMATION CONTACT

1800 652 755

info@rubbedin.com.au

Rubbedin Pty Ltd
Unit 1, 43 Neumann Road, Capalaba, QLD 4157 Australia

W magiccleaningproducts.com.au

f @magiccleaningproducts

CTCP-FS-02



SCAN ME